

How to setup netboot for u-boot easily...

To make this work, you need supported usb network card:

```
root@tegra20:/home/dpavlin# lsusb -d 0b95:7720
Bus 003 Device 002: ID 0b95:7720 ASIX Electronics Corp. AX88772
```

This card has to be enabled in kernel setup so that we can nfsboot from it!

```
tegra20:~$ cat /etc/fstab
```

Contents: [Dobrica Pavlinu's random unstructured stuff]

- Dobrica Pavlinu's random unstructured stuff (network setup)
- Dobrica Pavlinu's random unstructured stuff (dnsmasq, dhcp, tftp)
- Dobrica Pavlinu's random unstructured stuff (nfs)
- Dobrica Pavlinu's random unstructured stuff (u-boot)
- Dobrica Pavlinu's random unstructured stuff (kernel setup)
- Dobrica Pavlinu's random unstructured stuff (links)

network setup

```
root@x200:/export/tegra20# cat /etc/network/interfaces.d/enp0s25
#auto enp0s25
#iface enp0s25 inet dhcp

auto enp0s25
iface enp0s25 inet static
    address 192.168.4.1
    netmask 255.255.255.0
    post-up iptables -t nat -A POSTROUTING -s 192.168.4.0/24 -o wls1 -j MASQUERADE

root@x200:/export/tegra20# grep tegra20 /etc/hosts
192.168.4.100    tegra20
```

dnsmasq (dhcp, tftp)

```
dpavlin@x200:~$ cat /etc/dnsmasq.d/dhcp.conf
#interface=enp0s25

dhcp-range=192.168.4.50,192.168.4.150,12h

# this should be mac address of usb network adapter for target device
dhcp-host=00:14:d1:b0:63:1c,192.168.4.100

enable-tftp
#tftp-root=/srv/tftp

# Set the boot filename for netboot/PXE. You will only need
# this if you want to boot machines over the network and you will need
```

```

# a TFTP server; either dnsmasq's built in TFTP server or an
# external one. (See below for how to enable the TFTP server.)
#dhcp-boot=pxelinux.0

tftp-root=/export/tegra20
dhcp-boot=boot/boot.scr

log-queries
log-dhcp

```

nfs

`apt-get install nfs-kernel-server`

```

dpavlin@x200:~$ grep tegra20 /etc/exports
/export/tegra20      192.168.4.0/24(rw,sync,no_root_squash,no_subtree_check,fsid=1)

```

u-boot

Name of u-boot script file was found by looking into dnsmasq log and deducing which files u-boot requests as boot name, hence symlink.

```

dpavlin@x200:/export/tegra20$ ls -al boot.scr.uimg
lrwxrwxrwx 1 dpavlin dpavlin 13 Jan 13 11:51 boot.scr.uimg -> boot/boot.scr

dpavlin@x200:/export/tegra20$ cat boot/boot.cmd

tftpboot ${kernel_addr_r} /boot/zImage
tftpboot ${fdt_addr_r} /boot/tegra20-ventana.dtb
tftpboot ${ramdisk_addr_r} /boot/uInitrd

setenv bootargs root=/dev/nfs nfsroot=192.168.4.1:/export/tegra20 ip=192.168.4.100:192.168.4.1:19
#setenv bootargs ip=bootp root=/dev/nfs nfsroot=192.168.4.1:/export/tegra20 panic=10 nfsrootdebug
bootz ${kernel_addr_r} ${ramdisk_addr_r} ${fdt_addr_r}
# mkimage -C none -A arm -T script -d boot.cmd boot.scr

```

ip=dhcp should work here, but doesn't for me, mostly because kernel tries to init dummy0 and wifi network first instead of eth0, so we never get successfully mounted nfsroot :-(

kernel setup

To make this work, kernel for target device also has to have usb network drivers built in (I did try with modules but in combination with Debian's initrd it will never boot).

I have following usb network configuration enabled:

```
dpavlin@klin:/klin/Tegra/linux$ grep USB_NET .config | grep -v ^#
CONFIG_USB_NET_DRIVERS=y
CONFIG_USB_NET_AX8817X=y
CONFIG_USB_NET_AX88179_178A=y
CONFIG_USB_NET_CDCETHER=y
CONFIG_USB_NET_CDC_NCM=y
CONFIG_USB_NET_SMSC75XX=y
CONFIG_USB_NET_SMSC95XX=y
CONFIG_USB_NET_NET1080=y
CONFIG_USB_NET_CDC_SUBSET_ENABLE=y
CONFIG_USB_NET_CDC_SUBSET=y
CONFIG_USB_NET_ZAURUS=y
```

links

- for beagle bone

<https://bootlin.com/blog/tftp-nfs-booting-beagle-bone-black-wireless-pocket-beagle/>