inspiron-mini9_service manual_en-us.pdf

```
dpavlin@mini2:~$ lscpu
Architecture:          i686
 CPU op-mode(s):       32-bit
 Address sizes:        32 bits physical, 32 bits virtual
 Byte Order:           Little Endian
CPU(s):                2
 On-line CPU(s) list:  0,1
Vendor ID:             GenuineIntel
 Model name:           Intel(R) Atom(TM) CPU N270   @ 1.60GHz
   CPU family:         6
   Model:              28
   Thread(s) per core: 2
   Core(s) per socket: 1
   Socket(s):          1
   Stepping:           2
   CPU(s) scaling MHz: 100%
   CPU max MHz:        1600.0000
   CPU min MHz:        800.0000
   BogoMIPS:           3191.78
   Flags:              fpu vme de tsc msr pae mce cx8 apic sep mtrr pge mca cmov pat clflush dts a
                       tant_tsc arch_perfmon pebs bts cpuid aperfmperf pni dtes64 monitor ds_cpl
                       m
Caches (sum of all):
 L1d:                  24 KiB (1 instance)
 L1i:                  32 KiB (1 instance)
 L2:                   512 KiB (1 instance)

dmidecode

System Information
       Manufacturer: Dell Inc.
       Product Name: Inspiron 910
       Version: A04
       Serial Number: DRRZWF1
       UUID: 20202020-2020-2020-2020-202020202020
       Wake-up Type: Power Switch
       SKU Number: Not Specified
       Family: Not Specified
```

bios cell batery

Manual claims there is battery holder for BIOS cell battery -- there isn't. You will have to have battery with spot welded wings to which you can solder original wire to change it.